

Section GLASSWALK™ GP STRUCTURAL GLASS PAVER FLOOR SYSTEM

PART 1. GENERAL

1.1. Scope

- A. Furnish all floor system perimeter pieces, spanning members, spacer members, paver boots, paver units, sealant, all other materials, and labor necessary for complete floor system installation as indicated on the Drawings and specified herein.
- B. Related work specified elsewhere:
 - 1. Glass and Glazing
 - 2. Sealant
 - 3. Steel Containment Ring

1.2. Guarantee

- A. Floor system manufacturers shall guarantee for a period of five years from the date of purchase that the floor system will be free of defects in materials and factory workmanship, and that defective materials will be repaired or replaced immediately, after proper notification.
- B. The installing contractor shall guarantee for a period of five years against faulty installation workmanship due to on-site errors

1.3. Submittals

A. Submit assembly instructions and shop drawings as required to indicate methods of construction, location and spacing of anchorage, joinery, finishes, sizes, shape, thickness and alloy materials, paver units, and relationship to the adjoining work.

1.4. Material Storage and Handling

- A. Store material in a dry place, off the ground, where temperature will not exceed 90 degrees Fahrenheit.
- B. Handle material to prevent damage to finished surfaces. Do not install scratched

- or damaged components.
- C. After installation, protect finished surfaces from damage caused by ensuing work.

PART 2. PRODUCTS

2.1. Materials

- A. GlassWalk Glass Paver Grid System for Floors: extruded aluminum Glass Paver Grid System for floors as manufactured by GBA Architectural Products + Services, 877-280-7700, sales@gbaproducts.com www.gbaproducts.com
- B. Rubber Paver Unit Boots: ASTM D2000 rubber compound furnished with GBA Products + Services.
- C. Sealant: TradeMate Glass Block Sealant, furnished with GBA Products + Services Glass Block Grid System.
- D. Finish: Clear anodized matte finish.
- E. Glass block paver units: Nominal 8" x 8" x 1" thick, solid glass paver units, in color and pattern as selected.

PART 3. EXECUTION

3.1. Field Conditions

- A. Verify all applicable field dimensions and adjust as necessary to accommodate the floor system.
- B. Examine the supporting structure and containment ring to which floor system will be installed. Correct any conditions which are not constructed according to installation instructions and approved shop drawings furnished by the floor system manufacturer.

3.2. Installation

- A. Insert each paver unit into the paver boot.
- B. Assemble glass block grid floor system according to instructions furnished by the manufacturer into the prepared containment ring. Top surface of glass pavers shall finish flush with adjoining surface and exposed aluminum surface joints unless shown otherwise on the drawings.
- C. Apply sealant to completely fill the channel around each glass block paver unit and joints between aluminum grid members and wipe flush with top surface. Perform all sealant work in accord with the requirements of the Sealant Section of the specifications.

3.3. Clean-up

- A. Clean all exposed surfaces of the aluminum glass block grid system with clean, soft cloth and mild hand soap using gentle rubbing action. Do not use abrasive or solvent-type cleaners, detergents, or paint removers.
- B. Remove all labels from glass pavers and clean with soft cloth and water.

END OF SECTION